




# Asus Transformer Book T100TAR Front Camera Replacement

Replace and repair the front-facing camera on your tablet.

Written By: Alyssa Ballesteros



## INTRODUCTION

If the front-facing camera on your laptop is broken, this guide will teach you step-by-step on how to disassemble your laptop and replace the camera.

---



### TOOLS:

- [iFixit Opening Tools](#) (1)
  - [Phillips #0 Screwdriver](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — Front Camera




- Detach and separate the screen from the keyboard by pressing the silver release button at the base of the tablet.

## Step 2




- Take the metal spudger and insert it into the seam of the rear cover casing and gently pry upwards.
- If done correctly, you should feel the clips release.
- Ensure that all the clips are released by sliding the spudger along the four edges of the tablet.

 Do not force the clips to release. This will cause them to break, and if broken, the screen will become loose. Open the rear cover gently and with caution.




## Step 3




- Take off the rear case

## Step 4




- Unscrew two 5mm screws from the camera board using a Phillips #0 Screwdriver.

## Step 5



- Using a plastic opening tool, lift the white tab holding the power button cable, located on the camera board and pull out the cable strip.

## Step 6



- Also using the plastic opening tool, gently lift up and remove the large black strip connecting the camera board to the motherboard.

## Step 7



- Remove the camera board.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 11:05:21 AM.